



INFINITY

LAVABO

Miscelatore monocomando

lavabo monoforo

bocca 115 mm

scarico automatico 1"1/4

Single lever washbasin mixer


115 mm spout

with 1"1/4 automatic pop-up waste



**Cod. Aquamat
DA40051021**

**Cod. Iperceramica
10747**



LAVABO

Miscelatore monocomando

lavabo monoforo


bocca 170 mm

scarico automatico 1"1/4

Single lever washbasin mixer


170 mm spout

with 1"1/4 automatic pop-up waste



**Cod. Aquamat
DA40151021**

**Cod. Iperceramica
10748**



LAVABO

Miscelatore monocomando

lavabo monoforo - modello alto 317 mm

bocca 170 mm

senza scarico

Single lever washbasin mixer

high 317 mm


115 mm spout

with 1"1/4 automatic pop-up waste



**Cod. Aquamat
DA40354021**

**Cod. Iperceramica
10749**



BIDET

Miscelatore monocomando

bidet monoforo

bocca 105 mm

scarico automatico 1"1/4


Single lever bidet mixer

with 1"1/4 automatic pop-up waste



**Cod. Aquamat
DA40055021**

**Cod. Iperceramica
10750**



INFINITY


VASCA

Miscelatore monocomando
vasca esterno
attacco per flessibile 1/2" M
senza completo doccia
Single lever bath mixer
without shower set
1/2"M flexible connection



**Cod. Aquamat
DA40013021**

**Cod. Iperceramica
10751**




DOCCIA

Miscelatore monocomando
doccia esterno
attacco per flessibile 1/2" M
senza completo doccia
Single lever shower mixer
without shower set
1/2"M flexible connection




**Cod. Aquamat
DA40044021**

**Cod. Iperceramica
10752**




VASCA

Miscelatore termostatico
vasca esterno
SAFE TOUCH
attacco per flessibile 1/2" M
senza completo doccia
Thermostatic bath mixer
without shower set
1/2"M flexible connection




**Cod. Aquamat
DDT2721021**

**Cod. Iperceramica
10755**




DOCCIA

Miscelatore termostatico
doccia esterno
SAFE TOUCH
attacco per flessibile 1/2" M
senza completo doccia
Thermostatic shower mixer
without shower set
1/2"M flexible connection



**Cod. Aquamat
DDT0121021**

**Cod. Iperceramica
10756**




DOCCIA

Miscelatore termostatico
doccia incasso 1/2"
rubinetto d'arresto con uscita 1/2"
piastra ovale
Exposed part for 1 outlet con.therm.shower
stop valve
with concealed part



Cod. Huber
889.05IC.CR

Cod. Iperceramica
10757




DOCCIA

Miscelatore termostatico
doccia incasso 1/2"
deviastop 2 uscite 1/2"
piastra ovale
Exposed part for con.therm.shower valve
with 2 outlet deviastop
with concealed part



Cod. Huber
888.05IC.CR

Cod. Iperceramica
10759




DOCCIA

Miscelatore termostatico
doccia incasso 1/2"
deviastop 3 uscite 1/2"
piastra ovale
Exposed part for con.therm.shower valve
with 3 outlets deviastop
with concealed part



Cod. Huber
887.05IC.CR

Cod. Iperceramica
10760




DOCCIA

Miscelatore termostatico
doccia incasso 3/4"
rubinetto d'arresto con uscita 3/4"
piastra ovale
Exposed part for 1 outlet con.therm.shower
stop valve
with concealed part



Cod. Huber
889.55IC.CR

Cod. Iperceramica
10758



DOCCIA


Presad'acqua 1/2"

Wall elbow, 1/2" connection



Cod. Huber
67.03IC.CR

Cod. Iperceramica
10761



DOCCIA


Soffione laterale, attacco 1/2"

Body Jet, 1/2" connection



Cod. Huber
SS.315070.21

Cod. Iperceramica
10763



DOCCIA


Soffione laterale, attacco 1/2"

Body Jet, 1/2" connection



Cod. Huber
61.12IC.CR

Cod. Iperceramica
10762



DOCCIA


Miscelatore monocomando
doccia/vasca incasso 1/2"
deviatore 2 uscite 1/2" e 3/4"
piastra tonda

Exposed part for concealed S.L.
bath-shower valve
2 outlet automatic diverter
with concealed part



Cod. Huber
DA40021021

Cod. Iperceramica
10753



DOCCIA

Miscelatore monocomando
doccia incasso 1/2"
piastra tonda

Exposed part for concealed S.L.
shower valve
with concealed part



Cod. Huber
DA40030021

Cod. Iperceramica
10754

